



Hoist Suspensions



Plain Trolleys

Simply adjust the collars on the shaft to fit the flange of a beam. Gives mobility to your suspended load.

- Complies with ASME B30.11
- Drop-protect side plates
- Smooth travel
- Minimum headroom















Geared Trolleys

Simply adjust the collars on the shaft to fit the flange of a beam. Gives mobility to your suspended load.

- Complies with ASME B30.11
- Drop-protect side plates
- Smooth travel
- Minimum headroom















Beam Clamps

A rigging must-have. Beam clamps can be used to suspend a hoist from a beam or be used in reversal to hoist beams.

- Complies with ASME B30.20
- Drop-forged steel









